



# ENERGIZER™

## Foot Support

- Free-floating platform allows for intuitive rocking motion to help promote lower leg movement
- Invigorating rubber surface has diverse massage textures that target pressure points on the soles of your feet
- Three height settings (4", 5¼", and 6½") and up to 25° tilt



<b>Mfr #</b>	8068001
<b>Dimensions</b>	4½" H x 17¼" W x 13¼" D
<b>Warranty</b>	1 Year Limited
<b>Price</b>	

